

SOLYX- Static Cling Decorative Window Film Installation Instructions

NOTE: The side of the film contacting the backing paper is applied to the glass surface. For large sizes (such as for sliding doors), we recommend that two people work together to perform the installation.

DO NOT WET the backing paper/liner at any time.

Step-By-Step Installation Instructions

1. Measure your glass surface, transpose the measurements onto backing paper, then **trim to size with scissors or utility knife**. A straight edge is helpful for long cuts. Add 1/2" to 1" length before trimming. Perform final trim after installation on glass.

TIP: When using multiple pieces, match pattern before trimming or removing from backing paper.

2. Clean Glass. It is very important that the glass be clean.

TIP: Use a scraper to remove any paint splatters or hard materials that may be stuck to the door or window and clean thoroughly with any household window cleaner.

3. After cleaning window, but before starting to apply, **WASH YOUR HANDS!** This prevents dirt and oils from your hands from getting between film and the glass as you apply it.

4. Using a spray bottle filled with water add 1 to 2 drops of liquid soap. Set spray bottle to a mist setting. **Thoroughly WET GLASS, wetter is better.**

CAUTION: Make sure that NO WATER gets on backing paper.

TIP: Completely wetting the glass makes it easiest to position the film & squeegee out air bubbles.

5. Remove film completely from clear backing paper/liner and position on the glass. The side of the film touching the backing paper is applied to the glass surface.

TIP: Use the side of your hand to smooth out any large bubbles. The film will then "float" on the glass for you to move into its final position.

TIP: If film is misaligned just peel it off, re-spray, and reapply.

TIP TO REMOVE LINER: To separate the liner from the film take two pieces of scotch tape and stick them opposite each other at one corner...then pull these two pieces of tape apart and the liner will separate from the film. The static cling surface will now be exposed. Wet this surface.

6. Once in place, use your soap and water spray bottle to **wet the front of the film, then squeegee out all air bubbles** with a credit card.

TIP: Work from the top center of the film towards the sides and then down.

TIP: If an edge of the material will not lie flat, use a hair dryer on a low heat setting to warm the film until it becomes pliable. Remove heat and hold film in place for 60-90 seconds or until material cools to room temperature.

Removal and Storage for Re-use

To remove, simply peel the window film from any corner. It comes off cleanly leaving no residue. When not in use, window film must be replaced and stored on the original backing paper/liner. The side of the film that touched the glass should face the glossy side of the backing paper/liner.

Shower Enclosures - Install the decorative window film on the outside of shower stall. Steam and moisture will not affect our products.